



REPLACEMENT PARTS LIST

Gas Heating / Electric Cooling Package Units
14 SEER, 3-Phase, 460V Models
R8GE Series



R8GE GAS HEATING / ELECTRIC COOLING PACKAGE UNITS

14 SEER, 3 PHASE, 460V MODELS

DESCRIPTION	R8GEX36D072*	R8GEX36D096*	R8GEX48D096*	R8GEX48D120*	R8GEX60D096*	R8GEX60D120*
	1006852	1006853	1006854	1006855	1006856	1006857
ACCESS DOOR	296647	296647	296645	296645	296645	296645
ACCESS FITTING	663812	663812	663812	663812	663812	663812
ADAPTER (1" FILTER-FOR FILTER RACK)	285131	285131	285131	285131	285131	285131
AUTOTRANSFORMER (1200 VA)	621759	621759	621759	621759	621759	621759
BASE RAIL (LONG)	277552R	277552R	277552R	277552R	277552R	277552R
BASE RAIL (SHORT)	277551R	277551R	277551R	277551R	277551R	277551R
BLOWER DISCHARGE PANEL	281493R	281493R	281493R	281493R	281494R	281494R
BLOWER SHELF	283931R	283931R	—	—	—	—
BLOWER ASSEMBLY (11X10)	297219R	297219R	297219R	297219R	297219R	297219R
BLOWER MOTOR (1/2 HP, 3 TON)	100711601R	M0009036R	—	—	—	—
BLOWER MOTOR (1 HP, 4 TON)	—	—	100711604R	100711608R	—	—
BLOWER MOTOR (1 HP, 5 TON)	—	—	—	—	100711605R	100711609R
BLOWER WHEEL (11 X 10)	667277R	667277R	667277R	667277R	667277R	667277R
BOTTOM FILTER BRACKET	2C7791	2C7791	2C7791	2C7791	2C7791	2C7791
BOTTOM PAN ASSEMBLY	D05480R	D05480R	D05480R	D05480R	D05480R	D05480R
BLOWER PANEL ASSEMBLY	D05548R	D05548R	D05542R	D05542R	D05543R	D05543R
CAPACITOR (5/370)	01-0023	01-0023	01-0023	01-0023	01-0023	01-0023
CHARGING PORT CORE (NOT SHOWN)	662103	662103	662103	662103	662103	662103
CLOSE-OFF PANEL	D05693R	D05693R	D05682R	D05682R	D05683R	D05683R
COLLECTOR PAN ASSEMBLY (W/O RETAINER)	100677913R	100677914R	100677914R	100677915R	D10328	100677916R
COLLECTOR PAN GASKET	689506	689506	689506	689506	689506	689506
COMPRESSOR (ZP31K5E)	920137	920137	—	—	—	—
COMPRESSOR (ZP42K5E)	—	—	920138	920138	—	—
COMPRESSOR (ZP54K5E)	—	—	—	—	920139	920139
CONTACTOR (1 POLE, 30A)	621832	621832	621832	621832	621832	621832
CONTROL BOARD	919943	919943	919943	919943	919943	919943
CONTROL BRACKET	100715101	100715101	2A9611	2A9611	2A9611	2A9611
CORNER PANEL ASSEMBLY	D05630R	D05630R	D05628R	D05628R	D05629R	D05629R
CORNER POST	D09994R	D09994R	D09996R	D09996R	D09997R	D09997R
CRANKCASE HEATER (NOT SHOWN)	632576	632576	632576	632576	632576	632576
DRAIN PAN	669190R	669190R	669190R	669190R	669190R	669190R
DRAIN TUBE ASSEMBLY	663833	663833	663833	663833	663833	663833
DIVIDER PANEL ASSEMBLY	D05505R	D05505R	M0060722R	M0060722R	M0060722R	M0060722R
DUCT CAP ASSEMBLY	D05530R	D05530R	D05530R	D05530R	D05530R	D05530R
DUCT CAP	283101R	283101R	283101R	283101R	283101R	283101R
EXHAUST DUCT	263420R	263420R	263420R	263420R	263420R	263420R
FAN BLADE	667278R	667278R	667319R	667319R	667319R	667319R
FAN ORIFICE	263210R	263210R	295481R	295481R	295481R	295481R
FILTER DRIER (UNIFLOW, 8 IN ³)	669764	669764	669764	669764	669764	669764
FILTER SUPPORT BRACKET	—	—	2C7811	2C7811	2C7811	2C7811
FLAME ROLLOUT LIMIT SWITCH (320 ° F)	626547R	626547R	626547R	626547R	626547R	626547R
FLAME SENSOR	632396	632396	632396	632396	632396	632396
FRONT PANEL	298891R	298891R	298892R	298892R	298893R	298893R
FUSE (3-AMP) (NOT SHOWN)	632261	632261	632261	632261	632261	632261
GAS VALVE	904081	904081	904081	904081	904081	904081
HEAT EXCHANGER DIVIDER PANEL	D05071R	D05071R	D05072R	D05072R	D05075R	D05075R
HEAT EXCHANGER PANEL ASSEMBLY	100677906R	100677907R	100677909R	100677910R	100677911R	100677912R
HEX NUTS (BLACK)	606261	606261	606261	606261	606261	606261
HIGH PRESSURE SWITCH (NOT SHOWN)	632473	632473	632473	632473	632473	632473

Please specify the correct Model No., Serial No, and Part No. when ordering parts from the nearest authorized dealer or service center.

R8GE GAS HEATING / ELECTRIC COOLING PACKAGE UNITS

14 SEER, 3 PHASE, 460V MODELS

DESCRIPTION	R8GEX36D072*	R8GEX36D096*	R8GEX48D096*	R8GEX48D120*	R8GEX60D096*	R8GEX60D120*
	1006852	1006853	1006854	1006855	1006856	1006857
HINGE BRACKET	2C8081	2C8081	2C8081	2C8081	2C8081	2C8081
IGNITOR (208/230)	903179	903179	903179	903179	903179	903179
INDOOR COIL	664935R	664935R	664936R	664936R	664937R	664937R
INDUCER GASKET	689518	689518	689518	689518	689518	689518
INDUCER MOTOR	903162	903162	903162	903162	903162	903162
INSHOT BURNER	660812	660812	660812	660812	660812	660812
LIMIT SWITCH (185/165)	—	—	—	—	626445	—
LIMIT SWITCH (170/150)	626423	—	—	626423	—	—
LIMIT SWITCH (165/145)	—	626432	626432	—	—	—
LIMIT SWITCH (175/155)	—	—	—	—	—	626424
LOWER RACK BASE (FOR FILTER RACK)	2C7181	2C7181	2C7181	2C7181	2C7181	2C7181
LOW PRESSURE SWITCH - SELECT MODELS (NOT SHOWN)	632393	632393	632393	632393	632393	632393
MAIN BURNER ORIFICE (#43 DRILL) (NOT SHOWN)	661043	661043	661043	661043	661043	661043
MIDDLE RACK BASE	—	—	2C7821	2C7821	2C7821	2C7821
MOLDED PLUG (NOT SHOWN)	634718	634718	634718	634718	634718	634718
OUTDOOR COIL	1010327R	1010327R	664667R	664667R	1010326R	1010326R
OUTDOOR FAN MOTOR	622422R	622422R	622422R	622422R	622422R	622422R
PANEL MOUNT FITTING	664696	664696	664696	664696	664696	664696
PRESSURE SWITCH (NO. 0.90)	632424	632424	632424	632424	632424	632424
RETURN PANEL ASSEMBLY	—	—	296642R	296642R	296641R	296641R
SERVICE BRACKET	298552R	298552R	298552R	298552R	298552R	298552R
SERVICE FITTING LOCKNUT (NOT SHOWN)	663870	663870	663870	663870	663870	663870
SERVICE PANEL ASSEMBLY	D07241R	D07241R	296638R	296638R	296639R	296639R
SERVICE PORT CAP (BRASS) (NOT SHOWN)	663818R	663818R	663818R	663818R	663818R	663818R
SET OF WIRES (NOT SHOWN)	M0038354R	M0038354R	M0038354R	M0038354R	M0038354R	M0038354R
SUPPLY PANEL ASSEMBLY	D05558R	D05558R	D05552R	D05552R	D05557R	D05557R
TERMINAL BLOCK (NOT SHOWN)	632695	632695	632695	632695	632695	632695
TOP CAP (NOT SHOWN)	275291R	275291R	275291R	275291R	275291R	275291R
TOP FILTER BRACKET	2C7801	2C7801	2C7801	2C7801	2C7801	2C7801
TOP GRILLE (BLACK)	669404	669404	669335	669335	669335	669335
TOP PAN	M0034730R	M0034730R	M0034707R	M0034707R	M0034707R	M0034707R
TOUCH-UP PAINT (STERLING GREY) (NOT SHOWN)	903598	903598	903598	903598	903598	903598
TRANSFORMER (40 VA)	621709	621709	621709	621709	621709	621709
TXV	664349	664349	664350	664350	664275	664275
UPPER RACK BASE (20", OD FAN)	2C8131	2C8131	—	—	—	—
UPPER RACK BASE (24", OD FAN)	—	—	2C7191	2C7191	2C7191	2C7191
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and Part No. when ordering parts from the nearest authorized dealer or service center.

